

Operation Procedure of PC Tester

Step 1:

Take the GPS receiver outside where it has a clear view of the sky and away from tall trees, buildings, or other obstructions.

Step 2:


Execute the PCTesters tool on PC.

Step 3:

Set baud rate (4800) and com port (output port)


Step 4:

Click “on” icon



Step 5:

Tap on “cold” icon when you see the NMEA message running and then you can see the date changed to 2003/03/01 that means the *cold start* command is processed properly.



Note:

1. If the string with \$GP(NMEA message) is running, but can not see the satellite numbers and the column bars, please tap the **send** icon to execute **@GSV1** command then the satellite number and the column bar will appear.
2. Make sure the numbers of satellite are greater than 3 and the strength of satellite signal are greater than 40, and then GPS receiver should get fix within 3 minutes.